

FOG/SMOKE MACHINE INSTRUCTIONS

TO AVOID INJURY FROM HOT STEAM-KEEP AWAY FROM NOZZLE AT LEAST 2 FEET

1. Insert remote control into rear of machine
2. To avoid risk of electric shock, insert line cord plug into grounded outlet only
3. Fill reservoir with FOG FLUID
4. Close cap tightly. Push clear plastic feeder tube down through cap (if there is slack).
5. Warm up time for machines is approx. 7 minutes
6. When indicator light goes off (OR GOES ON IF IT WAS OFF) the machine is ready for use.
7. At times the indicator light will come on (OR OFF IF IT WAS ON) this is NORMAL the machine is simply recycling. Depress the switch only when light is OFF (OR ON IF IT WAS OFF).
8. To use timer mode, press "TIMER" button. Adjust "DURATION" knob for length of fog burst. Adjust "INTERVAL" knob for length of time between fog burst.
9. Allow fog machine to "COOL DOWN" before packing for transportation.

"IMPORTANT" Always make sure that there is enough FOG FLUID in the tank before turning the fog machine on. Activating the pump without fluid can cause damage to the pump and heat core.

"CAUTION" Vapor from this fluid may be irritating to some persons with allergenic sensitivity. Do not expose at close range to known asthmatics. Use in a well-ventilated area.